

ATTACHMENT INSTRUCTIONS

Your Tuatara HS Awning Bracket Kit includes:

2 x awning mounting brackets

12 x M8 bolts (hexagon head)

12 x self-locking nuts

INSTALLATION INSTRUCTIONS

1. Slide four hexagonal head bolts into each end of the bottom section of the Hardshell track system. Measure the distance required between each awning bracket, this will vary depending on the awning's size and weight.
2. With the desired distance between the brackets found, line up two bolts and fit the awning bracket in place. Add the self-locking nuts and loosely tighten. Repeat with the second mounting bracket.
3. To fix the awning to the mounting brackets - locate the four hexagonal head bolts that came supplied with the Side Awning, 270° Awning or Shower Tent. Slide the bolts into the metal track on the back of the awning.
4. Carefully lift the awning into position, this will take two people. Line up the awning bolts to the mounting brackets. Once aligned, add the nuts and fully tighten.



Regularly check all bolts and tighten.

WARRANTY INFORMATION

The warranty period and full details for this product are on the Kiwi Camping website

- www.kiwicamping.co.nz.