



Flexi Light Strip - Sail Track

Model No. KC005-035



INCLUDES:

- Flexi Light Strip
- Touch dimmer switch
- 5m 12V DC cord
- 5m 12V USB cord
- Battery terminal connector

SPECIFICATIONS:

Light Strip Size: 1235 L x 10 H x 50 W (mm)

Bulb Type: 72 LED's

Weight: 140g

Lumens: 1400

Amps: 1.2A

IP Rating: IP65

CAUTION:

Read and understand the product manual in full prior to using this product.
Use caution when connecting power source as this may cause injury when not carried out correctly.





USB cord should not be used with mains power. Use with 12V output only.

INSTALLATION INSTRUCTIONS

There are several ways that LED lights can be installed:

- Secure the sail track fixing into the track on the side of your awning, tent, boat or RV / motor home.
 - Secure the hook and loop tabs to fabric hanging points or a suitable location for extra reinforcement.
1. Plug the light into the dimmer, then plug the dimmer into the power cord of your choice. For example, use the 12V DC power cord if using a DC power output. **Note:** If using USB cord to power the lights, you may experience a dimmer light when compared to using a 12V DC cord due to the reduced wattage from the USB.
 2. Secure all connections by twisting the joiner at each connection point.



3. Plug the power cord into your chosen power source. Ensure all parts are connected and that there are no missing links. Turn on the power source.
4. To turn the light strip on or off, tap the red button  on the dimmer switch.
5. Once the lights are on, adjust the brightness by holding down the red button  on the dimmer switch.
 - a. To achieve maximum brightness, continue to press the red button .
 - b. To dim the lights, stop pressing the dimmer switch. Then press the red button  again, holding it down to dim.
 - c. Stop pressing the red button at any point to select the correct level of brightness.

WARNING

Use caution when connecting power sources as this may cause injury when not carried out correctly.

This product is IP65 rated and water-resistant, but not waterproof.

Handle with care; connection pins are easily damaged.

SAFETY INFORMATION

1. DO NOT look directly at LED lights.
2. LED light strips are designed for use in sheltered areas; we recommend keeping the connections out of the rain.
3. DO NOT place heavy objects on top of LED lights. Doing so may cause damage to the LED light.
4. DO NOT place LED lights close to heat/stoves or moving parts Doing so may cause damage to the LED light.
5. DO NOT overstress or overextend the cords. Doing so may damage connections and lead to product failure. Damaged or frayed cords should be replaced for safety reasons.
6. Ensure the power source is turned OFF before installation to avoid injury.

TROUBLESHOOTING

Ensure that all power connections are plugged in and switched on and that the DC connector plugs are not loose. The DC connection will light up red, showing that it is connected properly. If it does not illuminate, a fuse may be damaged; this can be replaced.

WARRANTY INFORMATION

The warranty period for this product is one year and full details are on the Kiwi Camping website - www.kiwicamping.co.nz.

The original purchaser of this product is offered a warranty if, during this time period, the product fails due to a fault in either materials or workmanship. Service under this warranty is available by returning the product, with your proof of purchase, to where it was purchased. If, after inspection, it is determined that the product is defective, we will repair or replace it (at our discretion) free of charge. This warranty does not cover misuse, damage caused by accident, storm or wind damage, mildew, neglect, UV degradation and fair wear and tear. Please note, the warranty on this Light Strip will be deemed void if the product is used for any purpose other than its intended use.



AS/NZS 60598.2.20
AS/NZS 60598.1



Distributed by: Aber Living, Hamilton, NZ
www.kiwicamping.co.nz
5383-11/22