

# GLOW LANTERN WITH POWER BANK

Model No. KC005-020

## INCLUDES:

USB cable



## SPECIFICATIONS:

**Lantern Run Time:** Low Mode 80hrs


**Weight:** 190g

**Size (mm):** 88 W x 70 H x 70 D

**Capacity:** 4000mAh

**Input:** 5V/1A **Output:** 5V/1A


**IP Rating:** IP54



## HOW TO USE

1. Press the button once, the LED indicator will turn on.
2. Press for 1.5 seconds, the lantern will turn on at middle light mode.
3. Shift through the light modes from one to another by pressing the button. Press once (LED indicator on). Long press (Middle Light). Press (Low Light). Press (High Light). Press (Strobe). Press (Flashing).
4. Press and hold button to turn off.

## CHANGING LIGHT MODES



## INPUT/OUTPUT FUNCTION

Micro USB input to charge Light/Power Bank



USB output to charge devices



## WARNING

1. Do not stare at the LED light directly.
2. In order to assure the life of the battery and its mechanical parts, please charge it at least once every six months.
3. Do not drop this product on a hard surface.
4. Do not place in or around direct heat/cold (more than 50°C above or 20°C below 0°C). This will greatly decrease battery life.
5. Do not touch the light if it has been on for a long period of time.
6. Keep out of the reach of children.
7. Keep children under supervision when using this product due to the strong magnet.
8. Do not place the product close to electronic medical devices such as pacemakers.