

## Assembly and User Instructions

### 1. Your high chair includes:

1 x Frame + Seat

### 2. Assembling the high chair

- Remove the high chair from its carry bag (illustration 1).
- Now proceed with extending the high chair.
- Extend the frame (from the X-hinge outward) in one quick jerk (illustration 2).
- Press down the locking mechanisms on the front and back of the high chair (illustration 4).
- Ensure that the locking mechanisms front and back of the high chair are secure (illustrations 3/ 4).
- Check that the seat fits properly and securely over the frame tubing. Pull down to secure (illustration 5).
- Fasten the two elastic loops to the sides of the footrest to secure the footrest to the frame (illustration 6).
- Always buckle up your child's belt / harness. Adjust belt / harness to fit your child.
- The high chair is now ready for use.

### 3. Disassembling the high chair

Follow the steps for assembling the high chair in reverse.

- Unfasten the two elastic loops on the sides of the footrest.
- Slightly lift the locking mechanisms front and back.
- Pull the lower locking mechanism forward to release it (illustration 7).
- Collapse the high chair.

Make sure when collapsing the high chair the fabric of the seat does not get tangled in any moving parts of the frame. Place the buckle of the belt on top of the collapsed high chair in order to prevent pinching and wear.

## Care Instructions

Remove the plastic caps situated under the fabric lining at the top of the frame to separate the seat from the frame (illustration 8). Clean the seat with a damp cloth or smooth brush. Use only a mild detergent to clean the metal and plastic parts. Please note: When returning the seat, always put back the plastic caps on top of the frame in order to prevent wear to the seat.





## READ THESE INSTRUCTIONS BEFORE USE AND KEEP IN A SAFE PLACE

**For your child's safety unconditionally follow these instructions to prevent slipping, falling and resultant injuries.**

- When collapsing and extending the high chair take every precaution to ensure that children are not in close proximity of the high chair to prevent their fingers getting jammed, etc.
- To avoid the risk of suffocation always remove the plastic sleeve and/or carrier bag from this item and keep it away from babies and toddlers
- This collapsible high chair is suitable for babies and toddlers 6 to 36 months in age or up to 25kg in weight.



## Never leave your child unattended!

- Toddlers in the high chair are the parents' responsibility and must be attended at all times.
- Always buckle up your child's belt and adjust it to fit your child to prevent your child falling or slipping out.
- To prevent unintended collapsing, always check that all locking mechanisms are properly fastened.
- Always position the high chair on a level and solid surface to avoid it tilting.
- Never use the high chair for children who cannot sit upright unsupported.
- Never carry the high chair along with your child in it.
- Never use the high chair as a step ladder and never position the high chair near a step ladder or platform.
- Pushing off tables or objects must be guarded against and prohibited.
- Be aware of the risk of open fire and other sources of extreme heat such as electrical heat sources, gas heaters etc. in the vicinity of the high chair.
- Never position the high chair near dangling curtain cords, drapes, telephone cords and other cables and/or belts.
- Never use the high chair when it has worn or broken parts.
- Never make modifications to the high chair that are not permitted under applicable rules and regulations.